



## hanging silk wallcoverings

### madison

**This product should be hung by a professional paper hanger with experience of hanging textile wallcoverings. If you would like us to recommend someone, contact us on 01892 615157.**

- Our silk wallcoverings are handmade from natural materials. Consequently there can be variations in both colour and pattern from roll to roll and from end to end of each roll.
- Throughout the installation, take care not to get adhesive onto the face of the wallcovering as it cannot be wiped off.
- Prepare the wall surface as appropriate for wallcoverings. If you believe the surface to be non-absorbent, contact us for further preparation advice.
- Use an undiluted ready-mixed PVA wallcovering adhesive (e.g. Beeline Medium Grade Wallcovering Adhesive or Murabond Standard Wallcovering Adhesive).
- Ensure that the walls are a similar colour to the wallcovering, particularly where it will make a joint.
- As the joins are intended to be visible, and consequently each drop will appear as a panel, plan the layout of drops in advance to create a balanced overall effect.
- Damp the back of the wallcovering with clean water, leaving about a 5cm margin at the edges. Allow to rest for at least 3 minutes.
- Paste the wall.
- Butt join the seams. Don't overwork them.
- After hanging 3 drops inspect the wallcovering to ensure you are happy with the results. If you have any doubts, stop hanging and contact us for advice. Please be aware that, as is standard in the industry, no claims can be considered beyond this point.

#### STEREO

PO Box 194 Tunbridge Wells, Kent TN2 5XY

Telephone: +44(0) 1892 615157

Fax: +44(0) 1892 615158

[stereo@stereowallcoverings.co.uk](mailto:stereo@stereowallcoverings.co.uk)

[www.stereowallcoverings.co.uk](http://www.stereowallcoverings.co.uk)