



hanging linen wallcoverings

oslo

This product should be hung by a professional paper hanger with experience of hanging textile wallcoverings. If you would like us to recommend someone, contact us on 01892 615157.

- Prepare the wall surface as appropriate for wallcoverings. If you believe the surface to be non-absorbent, contact us for further preparation advice.
- Use an undiluted ready-mixed PVA wallcovering adhesive (e.g. Beeline Medium Grade Wallcovering Adhesive or Murabond Standard Wallcovering Adhesive).
- Ensure that the walls are a similar colour to the wallcovering, particularly where it will make a joint.
- Paste the back of wallcovering.
- Butt join the seams. Adhesive can be wiped off with a damp cloth.
- After hanging 3 drops inspect the wallcovering to ensure you are happy with the results. If you have any doubts, stop hanging and contact us for advice. Please be aware that, as is standard in the industry, no claims can be considered beyond this point.

STEREO
PO Box 194 Tunbridge Wells, Kent TN2 5XY
Telephone: +44(0) 1892 615157
Fax: +44(0) 1892 615158

stereo@stereowallcoverings.co.uk
www.stereowallcoverings.co.uk